



IVT-Mod HowTo's

| | | |
|------------------|---|----------------------------|
| Project | IVT-Modular | |
| Description | | |
| State | Draft | x |
| | Review | <input type="checkbox"/> |
| | Released | <input type="checkbox"/> |
| | Note: Printouts are not under version control | |
| Responsible | | L. Breitenbach / A. Lepper |
| Creation | 05.05.2013 | |
| Module Name | IVT-Mod | |
| Hardware Version | | |
| Firmware Version | | |
| Product State | | |

Change history

| Edition | Rev. | Date | Author | Chapter(s) | Description |
|---------|------|------------|--------|------------|--|
| 0 | | 05.05.2013 | LBr | all | Creation, Configure Results |
| | | 15.05.2013 | LBr | all | Configure CAN-ID, Modify CAN-Bitrate |
| | | 22.05.2013 | LBr | | Get Version + Get Device-ID added |
| | | 28.05.2013 | LBr | | Alive added, Configure Results Note 2 added |
| | | | | | |

Table of Contents

| | | |
|----------|--|----------|
| 1 | Configuration | 3 |
| 1.1 | Configure Results | 3 |
| 1.1.1 | Example: Configure Result U2 to send the Voltage all 60 ms and store | 3 |
| 1.2 | Configure CAN-ID | 4 |
| 1.2.1 | Example: Changing CAN-ID | 4 |
| 1.3 | Modify CAN-Bitrate | 4 |
| 1.3.1 | Valid Prescalers | 5 |
| 1.3.2 | Example: Changing CAN-Bitrate | 5 |
| 2 | Retrieving Information | 5 |
| 2.1 | Get Version | 5 |
| 2.1.1 | Example: Retrieve Version | 5 |
| 2.2 | Get Device-ID | 6 |
| 2.2.1 | Example: Retrieve Device-ID | 6 |
| 2.3 | Alive | 6 |
| 2.3.1 | Example: Alive | 7 |

1 Configuration

1.1 Configure Results

- Power up the sensor.
The sensor retrieves the configuration from non volatile memory.
The device will send results as last stored.
- Send Command "MODE-STOP".
- The device responds "MODE-STOP".
The device leaves the measurement mode .
- Send Command "Config Result n".
- The device responds the "Config Result n".
- Send Command "STORE".
- The device responds "STORE".
The device stores the actual configuration in non volatile memory.
- Send Command "MODE-RUN".
- The device responds the "MODE-RUN".
The device enters the measurement mode.
- The device will deliver results as configured.

Note:

The new configuration will be lost after restart, if the command "STORE" is not applied to the device in "STOP-MODE".

1.1.1 Example: Configure Result U2 to send the Voltage all 60 ms and store

| Sender | Tgm | CAN-ID | DLC | D0 | D1 | D2 | D3 | D4 | D5 | D6 | D7 |
|--------|------------------------------|--------|-----|-------------------|----|-------------------|----|----|----|----|----|
| Host | Command "STOP" | 411 | 08 | 34 | 00 | 01 ⁽²⁾ | 00 | 00 | 00 | 00 | 00 |
| Device | Response "STOP" | 511 | 08 | B4 | 00 | 01 | 00 | 00 | 00 | 00 | 00 |
| Host | Set Config Result n (Note 1) | 411 | 08 | 22 ⁽¹⁾ | 02 | 00 | 3C | 00 | 00 | 00 | 00 |
| Device | Response Config Result n | 511 | 08 | A2 | 02 | 00 | 3C | 00 | 00 | 00 | 00 |
| Host | Command "STORE" | 411 | 08 | 32 | 00 | 00 | 00 | 00 | 00 | 00 | 00 |
| Device | Response "STORE" | 511 | 08 | B2 | 00 | 00 | 00 | 00 | 00 | 0E | 00 |
| Host | Command "START" | 411 | 08 | 34 | 01 | 01 | 00 | 00 | 00 | 00 | 00 |
| Device | Response "START" | 511 | 08 | B4 | 01 | 01 | 00 | 00 | 00 | 00 | 00 |

Note 1:

- D0 = 0x22 means Set Config Result U2
- D1 = 0x02 means cyclic transmit
- D2-3 = 0x003C means Time = 60ms

Note 2:

- D0 = 0x34 means Set Mode
- D1 = 0x00 means run-mode =STOP
- D2 = 0x01 means startup-mode =RUN

1.2 Configure CAN-ID

- Disconnect other sensors
- Power up the sensor.
The sensor retrieves the configuration from non volatile memory.
The device will send results as last stored.
- Send Command "MODE-STOP".
- The device responds "MODE-STOP".
The device leaves the measurement mode .
- Send Command "ID Res n" and the appropriate Serialnumber.
- The device responds the "ID Res n".
- Send Command "STORE".
- The device responds "STORE".
The device stores the actual configuration in non volatile memory.
- Send Command "MODE-RUN".
- The device responds the "MODE-RUN".
The device enters the measurement mode.
- The device will deliver results as configured with the new CAN-ID.

1.2.1 Example: Changing CAN-ID

Applying CAN-ID 0x624 to "Result Current" to the sensor with serial-number 1111= 0x00000457

| Sender | Tgm | CAN-ID | DLC | D0 | D1 | D2 | D3 | D4 | D5 | D6 | D7 |
|--------|------------------------------|--------|-----|----|----|----|----|----|----|----|----|
| Host | Command "STOP" | 411 | 08 | 34 | 00 | 01 | 00 | 00 | 00 | 00 | 00 |
| Device | Response "STOP" | 511 | 08 | B4 | 00 | 01 | 00 | 00 | 00 | 00 | 00 |
| Host | Set Config Result n (Note 1) | 411 | 08 | 10 | 06 | 24 | 00 | 00 | 04 | 57 | 00 |
| Device | Response Config Result n | 511 | 08 | 90 | 06 | 24 | 00 | 00 | 04 | 57 | 00 |
| Host | Command "STORE" | 411 | 08 | 32 | 00 | 00 | 00 | 00 | 00 | 00 | 00 |
| Device | Response "STORE" | 511 | 08 | B2 | 00 | 00 | 00 | 00 | 00 | 0E | 00 |
| Host | Command "START" | 411 | 08 | 34 | 01 | 01 | 00 | 00 | 00 | 00 | 00 |
| Device | Response "START" | 511 | 08 | B4 | 01 | 01 | 00 | 00 | 00 | 00 | 00 |

Now the Result Current will be sent with the new CAN-ID

| Sender | Tgm | CAN-ID | DLC | D0 | D1 | D2 | D3 | D4 | D5 |
|--------|----------|--------|-----|----|----|----|----|----|----|
| | | | | | | | | | |
| Host | Result I | 624 | 06 | 00 | 03 | xx | xx | xx | xx |
| Host | Result I | 624 | 06 | 00 | 04 | xx | xx | xx | xx |
| Host | Result I | 624 | 06 | 00 | 05 | xx | xx | xx | xx |
| | | | | | | | | | |

1.3 Modify CAN-Bitrate

- Disconnect other sensors
- Power up the sensor.
The sensor retrieves the configuration from non volatile memory.
The device will use the CANBitrate as last stored.
- Send Command "MODE-STOP".

- The device responds "MODE-STOP".
The device leaves the measurement mode .
- Send Command "RESTART with prescaler X"
- The device will restart using the new bitrate according to the new prescaler

1.3.1 Valid Prescalers

| Prescaler | CAN-Bitrate |
|-----------|-------------|
| 2 | 1000 Mbit/s |
| 4 | 500 kbit/s |
| 8 | 250 kbit/s |

1.3.2 Example: Changing CAN-Bitrate

Restart to 250kbit/s

| Sender | Tgm | CAN-ID | DLC | D0 | D1 | D2 | D3 | D4 | D5 | D6 | D7 |
|--------|--------------------------|--------|-----|----|----|----|----|----|----|----|----|
| Host | Command "STOP" | 411 | 08 | 34 | 00 | 01 | 00 | 00 | 00 | 00 | 00 |
| Device | Response "STOP" | 511 | 08 | B4 | 00 | 01 | 00 | 00 | 00 | 00 | 00 |
| Host | RESTART with prescaler 8 | 411 | 08 | 3A | 08 | 00 | 00 | 00 | 00 | 00 | 00 |

Restart to 500kbit/s

| Sender | Tgm | CAN-ID | DLC | D0 | D1 | D2 | D3 | D4 | D5 | D6 | D7 |
|--------|--------------------------|--------|-----|----|----|----|----|----|----|----|----|
| Host | Command "STOP" | 411 | 08 | 34 | 00 | 01 | 00 | 00 | 00 | 00 | 00 |
| Device | Response "STOP" | 511 | 08 | B4 | 00 | 01 | 00 | 00 | 00 | 00 | 00 |
| Host | RESTART with prescaler 4 | 411 | 08 | 3A | 04 | 00 | 00 | 00 | 00 | 00 | 00 |

2 Retrieving Information

2.1 Get Version

```
data_1 = Variante;
data_2 = Version;
data_3 = Revision;
data_4 = Day;
data_5 = Month;
data_6 = Year;
```

2.1.1 Example: Retrieve Version

| Sender | Tgm | CAN-ID | DLC | D0 | D1 | D2 | D3 | D4 | D5 | D6 | D7 |
|--------|------------------|--------|-----|----|----|----|----|----|----|----|----|
| Host | Command "STOP" | 411 | 08 | 34 | 00 | 01 | 00 | 00 | 00 | 00 | 00 |
| Device | Response "STOP" | 511 | 08 | B4 | 00 | 01 | 00 | 00 | 00 | 00 | 00 |
| Host | Get Version | 411 | 08 | 7A | 00 | 00 | 00 | 00 | 00 | 00 | 00 |
| Device | Response Version | 511 | 08 | BA | 01 | 01 | 05 | 1A | 04 | 0D | 00 |
| Host | Command "START" | 411 | 08 | 34 | 01 | 01 | 00 | 00 | 00 | 00 | 00 |
| Device | Response "START" | 511 | 08 | B4 | 01 | 01 | 00 | 00 | 00 | 00 | 00 |

- Variante 1
- Version 1
- Revision 5
- Day 26
- Month 4
- Year 13 (2013)

2.2 Get Device-ID

```

DeviceId.TYP          = data_1;
DeviceId.CURRENT      = data_2;
DeviceId.CURRENT      *= 16;
DeviceId.CURRENT      += (UInt16) (data_3 / 16);
DeviceId.VOLT_CHANNELS = (byte) (data_3 % 16);
DeviceId.T_O_I        = data_4;
DeviceId.COMMUNICATION = data_5;
DeviceId.VDD          = data_6;
DeviceId.SPARE        = data_7;

```

2.2.1 Example: Retrieve Device-ID

| Sender | Tgm | CAN-ID | DLC | D0 | D1 | D2 | D3 | D4 | D5 | D6 | D7 |
|--------|-------------------|--------|-----|----|----|----|----|----|----|----|----|
| Host | Command "STOP" | 411 | 08 | 34 | 00 | 01 | 00 | 00 | 00 | 00 | 00 |
| Device | Response "STOP" | 511 | 08 | B4 | 00 | 01 | 00 | 00 | 00 | 00 | 00 |
| Host | Get Devic-ID | 411 | 08 | 79 | 00 | 00 | 00 | 00 | 00 | 00 | 00 |
| Device | Response Devic-ID | 511 | 08 | B9 | 01 | 12 | C4 | 00 | 01 | 0C | 00 |
| Host | Command "START" | 411 | 08 | 34 | 01 | 01 | 00 | 00 | 00 | 00 | 00 |
| Device | Response "START" | 511 | 08 | B4 | 01 | 01 | 00 | 00 | 00 | 00 | 00 |

- DeviceId.TYP 1
- DeviceId.CURRENT 300
- DeviceId.VOLT_CHANNELS 4
- DeviceId.T_O_I 0
- DeviceId.COMMUNICATION 1
- DeviceId.VDD 12
- DeviceId.SPARE 0

2.3 Alive

The sensor will send an alive-message on restart. The message contains the following information

| Sender | Tgm | CAN-ID | DLC | D0 | D1 | D2 | D3 | D4 | D5 | D6 | D7 |
|--------|-----------------|--------|-----|----|----|----|----|----|----|----|----|
| Device | Response "STOP" | 511 | 08 | BF | XX | XX | YY | YY | YY | YY | 00 |

- D0 = 0xBF means Alive
- D1-2 = 0xFFFF is the CAN-ID accepting commands
- D3-6 = 0/YYYYYYYY is the serial number of the device

2.3.1 Example: Alive

| Sender | Tgm | CAN-ID | DLC | D0 | D1 | D2 | D3 | D4 | D5 | D6 | D7 |
|--------|-----------------|--------|-----|----|----|----|----|----|----|----|----|
| Device | Response "STOP" | 511 | 08 | BF | 04 | 11 | 00 | 00 | 03 | EC | 00 |

The sensor with the serial number 1004 (000003EC) has just started up and accepts commands on CAN-Id 411.