


CHAdEMO controller V1



Plug A

- 1 – SHUNT, connect to signal from SHUNT (SHUNT)
- 2 –
- 3 –
- 4 –
- 5 –
- 6 –
- 7 –
- 8 – VIN, 12V input (VIN)
- 9 –
- 10 – HV-relay coils + (HVCON1)
- 11 – HV battery -, connect to High Voltage - (GND2)
- 12 –
- 13 – HV battery +, connect to High Voltage +(VBAT)
- 14 –
- 15 –
- 16 –
- 17 –
- 18 –
- 19 – HV-relay coils - (HVCON2/IN0)
- 20 – 12V GND (GND)

Plug B (CHAdEMO)

- 1 – GND, connect to PIN1 (GND)
- 2 – Charge Start 1 , connect to PIN2 (IN1)
- 3 –
- 4 – Charge Enable, connect to PIN4 (OUT1)
- 5 –
- 6 –
- 7 – Proximity, connect to PIN7 (Proximity)
- 8 – CANH , connect to PIN8 (CANH)
- 9 – CANL , connect to PIN9 (CANL)
- 10 – Charge Start2, connect to PIN10 (IN0)
- 11 –
- 12 –